
## AQ100/AQ150 Power Supply Pin Installation and Removal Procedures



## To Install:

- 1. Select the appropriate plug for use in your country.
- 2. Align and hook the top edge of the pin plate to the edge of the recess.
- 3. Press the plate in the direction as shown in the diagram until it snaps in place.



## To Remove:

Slide the "OPEN" knob down until the pin plate is released.

